SENSAPHONE® REMOTE MONITORING SOLUTIONS

Sensaphone Express II

Phone Notification with Future Expansion



ASSURANCE

COUNTLESS INDUSTRIES DEPEND ON SENSAPHONE FOR THE MOST COMPREHENSIVE REMOTE MONITORING SOLUTIONS AVAILABLE. WHEN YOU NEED TO BE ABSOLUTELY SURE A REMOTE SITE IS STABLE, SECURE AND MONITORED AROUND THE CLOCK, THERE'S NO SUBSTITUTE FOR CERTAINTY.

Easy to use – everyday

The Sensaphone Express II is so easy to use just about anyone can figure it out. If not, we offer free tech support to walk you through it.

We've got a sensor for that

Sensaphone has a sensor for monitoring everything from climate conditions to security and more.

Your business is our business

With over 400,000 systems installed worldwide, we've put Sensaphone to the test in just about every application imaginable.

Suggested Applications



Agriculture

Know that the temperature, humidity, or other critical conditions where plants or animals live are in check while you're away.



HVAC

Use your Sensaphone Express II to monitor temperature, power failure and other conditions in heating and air conditioning applications.



Water & Wastewater

Use your Express II to monitor tank levels, flow rates and other critical conditions in water and wastewater applications.

Sensaphone Express II

Features and Specifications

Keypad

Makes programming simple and easy. LCD gives a quick visual status.

Power

Comes with a plug in power supply that also monitors for power failures.

Phone Line

Call up to 48 different phone numbers when an alarm has been detected.

Enclosure

The Expres II comes sealed in a NEMA 4X enclosure which allows it to be placed in less than ideal environments.

Output

Control a light, siren or other device. One output is standard, and up to 16 can be added.

Inputs

Accept four different input types from a wide range of sensors.









Battery Backup

Rest easy knowing that even if the power goes out, the Express II will keep monitoring.

Expansion

Need more than eight inputs? The Express II comes standard with 8, but can expand to 40.

Microphone

EXPRESS

Record messages in your own voice, listen in from over the phone or monitor for high sound alarms.

Popular Compatible Sensors & Accessories

2.8K Room Temperature Sensor FGD-0100	Zone Water Detection Sensor FGD-0056
2.8K Weatherproof Temperature SensorFGD-0101	Additional 10' of Water Rope FGD-0063
2.8K Temperature Sensor in	Infrared Motion Detection Sensor FGD-0007
Glass Bead Vial FGD-0107	Smoke Detection Sensor for 120VAC FGD-0049
Temp Alert Temperature Switch FGD-0022	Smoke Detector w/battery backup FGD-0049-B
Humidistat Humidity Switch FGD-0027	Float SwitchFGD-0222
PowerOut Alert Power Failure Switch FGD-0054	Multi-Point Wireless I/O FGD-0205
Magnetic Reed Door and Window Switch FGD-0006	Surge Suppressor for Power and Phone FGD-0067
Spot Water Detection Sensor FGD-0013	Bluetooth Cell Phone Interface FGD-0230

SENSAPHONE® 901 TRYENS ROAD **ASTON, PA 19014**

PH: 877-373-2700 F: 610-558-0222

WWW.SENSAPHONE.COM